


CUCINA
by *Giani*

IM-GCFS-8010B26022016



3 in 1 Snack Maker

Instruction Manual

Model Reference: GCFS-8010B

Introduction

Thank you for choosing the Cucina by Giani 3 in 1 Snack Maker. Before use, please read this manual. It gives important instructions about safety, use and maintenance of your appliance. Please keep for future reference.

Index

Important Information.....	02
Before and First Time Use.....	03
Making Omelettes/Waffles.....	04
Cleaning & Maintenance.....	05

What's Included	QTY
Snack Maker	1
Set of full Sandwich Maker Plates	1
Set of Waffle Plates	1
Set of Omelette Plates	1
Instruction Manual	1

Important Information

- Read these directions for use carefully before using the appliance and save them for future reference.
- Before connecting the appliance ensure that the voltage indication on the underside of the appliance corresponds with the mains voltage in your home.
- Connect the appliance to an earthed wall socket
Position the appliance so that:
 1. The power cord is not hanging over the edge of the table or a sink
 2. It is standing on a flat surface with sufficient free space around it.
- Never put the power cord near to or in contact with the hot surface of the appliance.
- Always preheat the cooking plate before starting to cook.
- Unplug the appliance after use.
- Avoid touching the metal parts as they become very hot.
- Never use sharp or abrasive items in contact with the cooking plate as this will damage the nonstick surface.
- Children should be supervised to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Keep the appliance and its cord out of reach of children less than 8 years.
- Always clean the appliance after use. Firstly unplug and allow the appliance to cool down. Never immerse the appliance in water. Avoid water running into the appliance.
- If the mains cord of this appliance is damaged, it must only be replaced by a qualified Electrician.
- The appliance is not intended to be operated by means of an external timer or separate remote control system.

Close adult supervision must be provided when this appliance is used near children.

This appliance must only be used by responsible adults.

Keep this appliance away from children.

Before and First Time Use


- Clean the baking plates with a damp cloth or sponge.
- Slightly grease the baking plates with a little butter or cooking oil.
- Plug in the Snack Maker and heat up the plates until the green ready to cook pilot light goes off. The snack maker is ready for use

Note: when using this snack maker for the first time, a slight smell may occur. This is normal because of the initial heating of the internal components.

- This snack maker incorporates detachable cooking plates. Choose your desired cooking plate for the task to be performed.

Making toasted sandwiches

- When inserting the plate, make sure the mountings of the plate fits into the cavities on the hinged side of the device and press down on the plate until it clicks and is locked into place.
- Put the mains plug into the wall socket. The red power light and green power light will both illuminate to show that the snack maker is heating.
- Prepare the bread and filling for your sandwich while the snack maker is pre-heating.
- Wait until the green light goes off. The sandwich maker is then at the correct temperature for use.
- To obtain an even golden brown result, you can slightly butter the side of the bread in contact with the plates.
- Lay the slices of bread with the buttered side on the lower cooking plate, place your filling and cover with the second slices of bread with buttered side up. You can toast only one sandwich if you wish. For optimal result, fillings should be placed well within the sandwich slices.
- Lower the upper cooking plate carefully onto the bread until the snack maker is tightly clamped.
- Open the snack maker after 3-5 minutes and check whether the toasted sandwich is sufficiently 'brown'. The cooking time required to obtain crisp brown sandwiches depends on the type of bread, fillings and your personal taste.
- Use a non-metallic utensil (e.g. Wooden spatula) to remove the toasted sandwich.
- Do not use sharp or abrasive kitchen utensils.
- Unplug the snack maker from the wall socket after use and allow to cool before storage.
- Do not attempt to remove or change the cooking plate until it has fully cooled down.




Note: During cooking, the green ready to cook pilot light cycles on and off to maintain the appliance at the correct temperature.

Making Omelettes

When inserting the plate, make sure that the mountings of the plate fit into the cavities on the hinged side of the device, Press down the plate until it clicks and is locked into place.

- Put the mains plug into the wall socket. The red power light and green power light will illuminate to show that the snack maker is heating.
- Prepare the eggs and filling for your omelette while the omelette plates are pre-heating.
- Wait until the green light goes off, the snack maker is then at the correct temperature for use.
- Pour the filling in the lower side of the omelette plate. For optimal result, fillings should be placed well within the plate.
- Lower the upper cooking plate carefully until the plates are tightly clamped.
- Open the snack maker after 2-3 minutes and check whether the omelette is sufficiently cooked.
- Use a non-metallic utensil (e.g. wooden spatula) to remove the omelette. Do not use sharp or abrasive kitchen utensils.
- Unplug the snack maker from the wall socket after use.
- Do not attempt to remove or change the cooking plate until it has fully cooled down.




Note: During cooking, the green ready to cook pilot light cycles on and off to maintain the appliance at the correct temperature.

Making Waffles

When inserting the plate, make sure that the mountings of the plate fit into the cavities on the hinged side of the device, Press down the plate until it clicks and is locked into place.

- Put the mains plug into the wall socket. The red power light and green power light will illuminate to show that the snack maker is heating.
- Prepare the waffle mixture while the waffle plates are pre-heating.
- Wait until the green light goes off, the snack maker is then at the correct temperature for use.
- Pour the filling in the lower side of the waffle plate.
- Lower the upper cooking plate carefully until the plates are tightly clamped.
- Open the snack maker after 2-3 minutes and check whether the waffle is sufficiently cooked.
- Use a non-metallic utensil (e.g. wooden spatula) to remove the waffle. Do not use sharp or abrasive kitchen utensils.
- Unplug the snack maker from the wall socket after use.
- Do not attempt to remove or change the cooking plate until it has fully cooled down.



Note: During cooking, the green ready to cook pilot light cycles on and off to maintain the appliance at the correct temperature.

Cleaning and Maintenance

Never use aggressive or abrasive cleaning agents and materials, as this damages the non-stick coating of the plates.


1. Unplug the appliance.
2. Let the appliance cool down properly in open position.
3. First remove excess oil from the plates with a piece of kitchen paper before you clean them.
4. Use a wooden or plastic spatula to remove food residues (for example solidified cheese) from the cooking plates.
5. Do not use metal, sharp or abrasive utensils.
6. Clean the cooking plates with a moist soft cloth or sponge and soapy water.
7. Clean the outside of the appliance with a moist cloth.

Never immerse the appliance into water or liquid.

The appliance can be stored in a vertical position.

Operating Voltage: 220-240V ~50Hz

Power: 640-760W





CUCINA
by *Giani*

Giani Limited - SK2 6RH