



WC0837 13032018



Bluetooth Headphones

Instruction Manual

Model Ref: WC0837

Introduction

Thank you for choosing these Bluetooth Headphones. This product is manufactured to the highest standards of performance and safety.

Before use, please read this manual carefully. It gives important instructions about safety, use and maintenance of your device.

Remove all packaging material. You may wish to keep the packaging for future use or storage of your device. Alternatively, dispose of accordingly.

Index

Important Safety Information	02
Product Specifications	04
Features	05
Product Overview	06
Controls	07
Functions	08
Troubleshooting	09
Disposal Information	10

IMPORTANT SAFETY INFORMATION

WARNING - To reduce the risk of fire, electric shock, or injury:

1. **DO NOT** turn up the volume so high that you can't hear what's around you.
2. **DO NOT** expose the Bluetooth Headphones to excessive heat.
3. **DO NOT** drop your Bluetooth Headphones.
4. **DO NOT** allow your Bluetooth Headphones to be submerged in water.
5. **DO NOT** use any cleaning agents containing alcohol, ammonia, benzene, or abrasives
6. The Bluetooth Headphones should not be exposed to dripping or splashing water.
7. Be sure to listen at reasonable volumes for reasonable periods of time.
8. Be careful not to adjust the volume continuously upwards as your hearing adapts.
9. You should use caution or temporarily discontinue use in potentially hazardous situations.
10. Excessive sound pressure from the earphones and headrest can cause hearing loss.
11. Using the Bluetooth Headphones with both ears covered while driving is not recommended and may be illegal in some areas while driving.
12. For your safety, avoid distractions from music or phone calls while in traffic or other potentially dangerous environments.

13. If cleaning is required use a damp non abrasive cloth or sponge with a small amount of washing up liquid.
14. The integrated battery should not be exposed to excessive heat such as sunshine, fire or the like.
15. Operate or store in a place where temperature is between -15°C (5°F) and 55°C (131°F) (up to 90% relative humidity).
16. Battery life may be shorter in high or low temperature conditions.

PRODUCT SPECIFICATIONS

Sensitivity	92dB @ 3Mw / 1KHz Total Harmonic
Distortion	1%
Bluetooth	V4.2
Output Power	2.4 - 2.480 GHz
Charging Interface	Micro-USB
Battery Type	Lithium Polymer
Battery Capacity	200mAH
Charging Time	Approx. 1 Hour
Talking Time	Approx. 4 Hours
Music Playing Time	Approx. 3 Hours
Standby Time	Approx. 5 Hours
Drive Unit	Φ 40mm
Frequency Range	20Hz - 20KHz
Impedance	32Ω

FEATURES

Bluetooth Play

Support pairing Bluetooth devices to play music such as mobile phone, tablet and TV.

Hands-Free Calls

Supports hands-free calls with the built-in high sensitivity microphone making phone calls a breeze.

Incoming Call

It will announce the phone number when you have a coming call, it is more convenient.

iOS & Android Battery Display

The mobile phone real-time displays the headphones battery life, let you know the earphone battery level.

Auto-Off Eco Mode

If the bluetooth connection to the connected device is stopped, then the device will enter standby after 5 minutes of inactivity.

Auxiliary Input

Use your Bluetooth Headphones directly with your devices by connecting a 3.5mm headphone cable into the AUX jack.

Rechargeable Lithium Battery

The Bluetooth Headphones are supplied with a built-in rechargeable lithium battery.

Intelligent Charging

The voice will announce "*please charge*" when the battery power is low. When fully charged it will automatically cut off power to avoid battery charging too much and potentially damaging the battery.

PRODUCT OVERVIEW

1. Skip Track/Volume Up
2. Previous Track/Volume Down
3. Power On/Off
4. LED Power Indicator Light
5. Charging Port
6. Microphone
7. 3.5mm AUX in Port



ACCESSORIES



3.5mm AUX Cable



Micro USB Cable



Instruction Manual

CONTROLS

Skip Track/Volume Up (1)

- Short press to skip the track.
- Long press to increase the volume.

Previous Track/Volume Down (2)

- Short press to play the previous track.
- Long press to decrease the volume.

Power On/Off (3)

Long press the power button (3) to activate the Bluetooth Headphones. A blue and green light will flash meaning the Bluetooth Headphones have entered the Bluetooth pairing state. Long press the power button again to turn the Bluetooth Headphones off.

When connected to a device via Bluetooth you can short press the power button to answer a phone call or you can long press to deny the call. Once you are finished talking short press the power button to hang up. Pressing the power button twice will redial the last called number.

Charging Port (5)

Use the supplied micro USB cable to charge. Connect to a USB Power Source.

3.5mm AUX in Port (7)

Use the supplied auxiliary cable to play audio media from any device with a 3.5mm AUX in port.

FUNCTIONS

Bluetooth Pairing

When pairing Bluetooth devices, a light will flash blue and green (4) indicating that the Bluetooth Headphones are searching for Bluetooth devices. Locate 'WC0837' on the device you are trying to connect via the Bluetooth settings to pair the device. Upon successful connection the Bluetooth Headphones will announce "Connected Successfully" and the light will change to a solid blue colour.

Using the headphones with a cable

Insert the 3.5mm AUX cable (supplied) into the AUX in Port (7), this will cause the Bluetooth Headphones to automatically power off. The Bluetooth Headphones will now be usable as a standard pair of headphones with no drain on the battery.

Low Battery

When the battery is low, the headphones will announce "Low battery, please charge", and then automatically shut down.

Charging the Headphones

Insert the small end of the charging cable into the Charging Port (5) on the Bluetooth headphones, then plug the large end into a powered USB port. A solid red light will appear while the Bluetooth Headphones are charging. When the Bluetooth Headphones are fully charged the Red light will turn off.

Note: It is recommended to charge your Bluetooth Headphones once a month when not in use to prevent loss of power to the battery.

Auto Power Off

If the Bluetooth Headphones aren't paired to a device, they will automatically turn off after 5 minutes of inactivity in order to save power.

TROUBLESHOOTING

Problem	Solution
The Bluetooth Headphones will not turn on.	Make sure your Bluetooth Headphones have not run out of battery. Connect it to a power source via the included USB cable.
Pairing is unsuccessful after multiple attempts Playback Time	Check if the indicator light is flashing blue & green. If the indicator light is off, please switch the power button to turn on the headphones. If the Bluetooth light still doesn't come on after holding the power button, please charge the Bluetooth Headphones.
	Ensure that the Bluetooth Headphones are not already connected to another bluetooth device.
Interference or static during playback	Reduce the distance between the Bluetooth Headphones and the paired Bluetooth device.
	Please check the battery level of the Bluetooth Headphones (via the paired Bluetooth device) and charge if necessary.

DISPOSAL INFORMATION

IMPORTANT INFORMATION FOR CORRECT DISPOSAL
OF THE PRODUCT IN ACCORDANCE WITH EC
DIRECTIVE 2002/96/EC

At the end of its working life, this product must NOT be disposed of as urban waste.

It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Disposing of a electrical product separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of electrical products separately, the product is marked with a crossed-out wheeled dustbin.



AUDIAL

Wellington Grove,
Stockport, SK2 6RH



2011/65/EU